Using the USBHost Library


Overview

The Arduino Due supports reading from USB devices through the Arduino USBHost library.

This guide it to print the key presses of a USB keyboard to the serial monitor.

In the Arduino IDE, go to **Sketch > Include Library > Manage Libraries** (or **Tools > Manage Libraries...** in the Arduino IDE v2).

In the library manager, type "usbhost" in the search bar and click **[Install]** in the box with the USBHost library.




💿 Library Manager

ype	All	~	Topic	AE	usbhost	
Allo Due sup	board to ap	pear	ation as a L	with USB pe JSB host, en	the state state of the	abdrives. The USBHost library allows an Arduino I like USB mice and keyboards. USBHost does not pards that have an internal hub.
Vers	sion 1.0.4] ~	I	rstall]		

In the Arduino IDE v2:

File Edi	t Sketch To	ools Help	
	BB	Auto Format	Ctrl+T
		Archive Sketch	
	LIBRARY	Manage Libraries	Ctrl+Shift+I
	usbhos	Serial Monitor	Ctrl+Shift+M
1	Туре:	Serial Plotter	



Setup

Connect the adapter cable to the native USB port and the cable for programming into the programming port. In this case, the blue cable is for programming and the black cable connects the

keyboard. Then, connect the keyboard to the adapter cable.



Code

```
// Include the KeyboardController library
#include <KeyboardController.h>
// Initialize USB Controller
USBHost usb;
// Attach Keyboard controller to USB
KeyboardController keyboard(usb);
void setup() {
  Serial.begin(9600); // open a serial port
}
void loop() {
  usb.Task();
}
void keyPressed() {
  // Get the ASCII value of the key pressed.
 int key = keyboard.getKey();
  if (key != 19) {
   // Pressed key is not 'Enter'
    Serial.write(key);
  }
```

```
else {
    // Enter key pressed, start a new line
    Serial.println();
  }
}
```

Code Explanation

First, we include the KeyboardController library and set up the keyboard.

In the setup function, we initialize a serial port. In the loop function, we call usb.Task to process keyboard input.

When a key is pressed, we print the key to the serial monitor with Serial.write. If the pressed key is the enter key, we start a new line.

Running the Code

Make sure the keyboard is plugged into the adapter. Then, open the serial monitor and press some keys on the keyboard.

The serial monitor should behave like a text editor, displaying each pressed key. Press enter to start a new line. This is the output of pressing some keys:

this is a test for usbhost library on arduino due
newline
abcdefg